

## HOW TO ADMINISTER FLUMIST®

1

**Check expiration date.** Product must be used before the date on sprayer label.

2

Remove rubber tip protector. Do not remove dose-divider clip at the other end of the sprayer.

3

With the patient in an upright position, place the tip just inside the nostril to ensure FluMist® is delivered into the nose.

4

With a single motion, depress plunger **as rapidly as possible** until the dose-divider clip prevents you from going further.

5

Pinch and remove the dose-divider clip from plunger.

6

Place the tip just inside the other nostril and with a single motion, depress plunger **as rapidly as possible** to deliver remaining vaccine.

DO NOT INJECT. DO NOT USE A NEEDLE.



**Note:** Active Inhalation (i.e., sniffing) is not required by the patient during FluMist® administration.